

Electronic Design for Windows
EDWINXP



Print Manager

VISIONICS

© Norlinvest Ltd, BVI. Visionics is a trade name of Norlinvest Ltd. All Rights Reserved. No part of the Print Manager document can be reproduced in any form or by any means without the prior written permission of Visionics. Print Manager document is subjected to change without notice. Visionics will make changes in a manner that will not affect dependent systems.

Unauthorized duplication, in whole or part, of this document by any means, mechanical or electronic, including translation into another language, except for brief excerpts in published reviews, is prohibited without the express written permission of Visionics.

Visionics, EDWinXP, Docone, EDComX, SimWinXP and Mixed Mode Simulator and their respective logos are trademarks or registered trademarks of Visionics. Unauthorized duplication of this work may also be prohibited by local statute.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Visionics. The information contained herein is the proprietary and confidential information of Visionics or its licensors, and is supplied subject to, and may be used only by Visionics's customer in accordance with, a written agreement between Visionics and its customer. Except as may be explicitly set forth in such agreement, Visionics does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Visionics does not warrant that use of such information will not infringe any third party rights, nor does Visionics assume any liability for damages or costs of any kind that may result from use of such information.

Contents

Print Manager	4
Invoking the Print Manager.....	4

Print Manager

Print Manager allows printing the project designs and various files generated from different modules of the program with ease at a single stretch. The set of options provided in this utility makes it much easier for printing the various files individually or in groups. The library components available in the project library may also be printed. Each file to be printed may be previewed and the printing scale may be changed as required.


Invoking the Print Manager

This utility can be invoked from Project Explorer in the following ways.

- Right click Project [Untitled] and select Print Manager from the list.
- Select Print Manager from the Tasklist or from the Task toolbar.

Note: By default, the task toolbar will not be displayed. It may be enabled from View menu in the Project Explorer.

Print Manager appears as shown in figure below.



Double click on the workspace so that the required layers, pages etc is added to the print queue. For printing the circuit, right click and select **Print Now**.